

# Hot HumRZ H2 Hood Scoop by ASAP, LLC

## Installation Instructions

Thank you for purchasing our custom hood scoop for HUMMER H2. Please read and follow these installation instructions carefully for proper installation.

1. Remove hood handles and hood vent. Clean hood with alcohol or wax and grease remover.
2. With hood scoop upside down on a protected surface, screw align rods (provided) in 4 mounting nutserts.
3. Remove backing on 2 sided tape.
4. with help, carefully place align rods though mounting holes on hood (where hood handles previously mounted) ensuring the back of the hood scoop is aligned with the back of the hood, and push scoop into place.
5. From under hood, remove align rods, one at a time, so you can use remaining rod on each side maneuver buckets when starting mounting bolts. (Tip: just start mounting bolts and use it to maneuver bucket for the remaining mounting bolt).
6. When all four are started, tighten
7. For installation support, call 877-959-2727.

